


EMBLEM-X2500iA



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-7	F67-4901	SPOOL	36	F62-2001	ROLLER CLUTCH
1	F62-7801	DRAG KNOB	37	F73-2501	SPACING SLEEVE
2	F71-0001	DRAG WASHER RET	38	637-5702	BALL BEARING C
3	F67-4301	DRAG KNOB CLICK PLT	39	F63-3501	PINION WASHER
4	F69-0901	DRAG WASHER	40	F65-2501	PINION GEAR
5	F67-6401	EARED WASHER	41	F67-4601	BODY
6	F67-6301	KEY WASHER	42	F65-1901	A/R CAM SPRING
8	F70-4901	SPOOL CLICK LEAF SPRING	43	F65-1801	A/R LEVER
9	E39-3100	SPOOL WASHER	44	F65-2201	WORM SHAFT BUSH
10	E12-2303	CLICK LEAF SPRING HOLDER	45	F65-2101	WORM SHAFT GEAR
11	E36-5301	CLICK GEAR	46	F65-2001	WORM SHAFT
12	F65-2701	MAIN SHAFT	47	375-4101	WORM SHAFT WASHER
13	341-9203	ROTOR NUT	48	F65-2301	WORM SHAFT COLLAR
14	B55-7601	ROTOR NUT LOCK SCREW	49	F65-2401	WORM SHAFT RET
15	F62-3407	ROTOR	50	F65-2601	OSC SLIDER
16	F62-5201	LINE ROLLER SCREW	51	F62-2601	OSC PAWL
17	F62-3504	BAJL ARM	52	F62-2701	OSC PAWL BUSH
18	F62-5101	BALL BEARING A	53	375-0801	OSC PAWL WASHER
19	F62-5001	LINE ROLLER	54	F62-2901	OSC SLIDER COVER
20	F67-4701	BAIL	55	E15-0204	OSC SLIDER COVER SCREW
21	F69-1101	BAIL SPRING SHAFT	56	F65-2902	SHIELD PLT
22	F62-9801	BAIL SPRING	57	F65-3102	REAR COVER
23	F62-3701	BAIL ARM PIN	58	E24-8101	REAR COVER SCREW
24	F63-1801	BAIL HOLDER WASHER	59	F65-2801	DRIVE GEAR
25	351-6101	BAIL ARM SCREW	60	375-8502	DRIVE GEAR WASHER
26	F63-1904	BAIL SPRING COVER	61	637-5702	BALL BEARING D
27	352-2501	BAIL SPRING COVER SCREW	62	F65-3005	SIDE COVER
28	F62-4601	BAIL TRIP PLT	63	E15-7502	SIDE COVER SCREW A
29	F62-4701	BAIL TRIP LEVER	64	E13-0501	SIDE COVER SCREW B
30	F63-2104	BAIL TRIP COVER	65	F40-4801	HANDLE COLLAR
31	F67-5501	BEARING RET A	66	363-8511	HANDLE SCREW
32	E24-7402	BEARING RET SCREW	67	F65-3502	HANDLE SCREW CAP
33	F63-1201	BALL BEARING B	68	F69-3301	HANDLE
34	F67-5401	BEARING RET B	69	F71-1801	LINE ROLLER COLLAR
35	F62-2201	ROLLER CLUTCH RET			