

6Y3308011

paraktiopsarema.gr

Daiwa
COMMITTED TO TOTAL QUALITY




SPINNING REEL

EMBLEM-Z2500iA

/ 1500 / 2000

Please order by parts number, not key number
Bitte Best.-Nr. angeben (Nicht "Key"-Nr.)
Veuillez indiquer le numero de la pièce (Non "Key" No.)



Key No.

Parts No.

Parts Name

Ersatzteilbezeichnung

2-7

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

6F653601
6F632801
6F710001
6F674301
6F690901
6F678401
6F676301
6F653701
6F704901
6E393100
6E122303
6E365301
6F652701
63419204
6B557601
6F623403
6F625201
6F623503
6F625102
6F625001
6F653201
6F691102
6F778101
6F623701
6F631801
63518101
6F631802
63522504
6F624601
6F624701
6F632102
6F675501
6E247402
6F631201
6F675401
6F622201
6F622001
6F732501
66375702
6F633501
6F652501
6F651801
6F651901
6F651801
6F652201
6F652101
6F652001
63754100
6F652301
6F652401
6F652601
6F622601
6F622701
63750800
6F622901
6E150204
6F652901
6F653101
6E248103
6F652801
63758500
66375702
6F653001
6E157502
6E130501
6F404801
63638511
6F653501
6F693201
6F701801
6F731101
6F777701

Spool Assembly
Drag knob
Drag washer retainer
Drag knob click plate
Drag washer
Eared washer
Key washer
Spool Assembly
Spool click leaf spring
Spool washer
Click leaf spring holder
Click gear
Main shaft
Rotor nut
Screw (A)
Rotor
Screw (B)
Ball arm
Ball bearing (A)
Line roller
Ball assembly
Ball spring shaft
Ball spring
Ball arm pin
Washer (A)
Screw (C)
Ball spring cover
Screw (D)
Ball trip plate
Ball trip lever
Ball trip cover
Bearing retainer (A)
Screw (E)
Ball bearing (B)
Roller clutch retainer
Anti-reverse pawl
Roller clutch
Spacing sleeve
Ball bearing (C)
Collar (A)
Pinion gear
Body assembly
Anti-reverse cam spring
Anti-reverse lever
Collar (B)
Worm shaft gear
Worm shaft
Washer (B)
Collar (C)
Worm shaft retainer
Oscillating slider
Oscillating pawl
Collar (D)
Washer (C)
Oscillating slider cover
Screw (F)
Plate
Rear cover
Screw (G)
Drive gear
Washer (D)
Ball bearing (D)
Side cover
Screw (H)
Screw (I)
Collar (E)
Screw (J)
Handle screw cap
Handle assembly
Collar (F)
Washer (E)
Collar (G)

Spüle Komplet
Bremsknopf
Spriegel
Ratschenhelbe für bremsknopf
Bremschelbe
Bremschelbe
Biozenschelbe
Spüle Komplet
Spulensperblettfeder
Spulenschelbe
Ratschenfedertaher
Ratschenrad
Hauptflache
Mutter für Umlaufkappe
Schraube (A)
Umlaufkappe
Schraube (B)
Bügelarm
Kugellager (A)
Schmurführflächchen
Bügel Komplet
Achse für Bügelfeder
Bügelfeder
Stift für Bügelarm
Schelbe (A)
Schraube (C)
Bügelfederabdeckung
Schraube (D)
Platte für Bügelauflöser
Bügelauflöserhebel
Deckung für Bügelauflöserhebel
Kugellagerdichtungsschelbe (A)
Schraube (E)
Kugellager (B)
Staubmanschette
Rücklaufsperrklinke
Aufnahme für Rotor
Bremsbuchse
Kugellager (C)
Buchse (A)
Ritzel
Gehäuse Komplette
Feder für Rücklaufsperrmocken
Rücklaufsperrhebel
Buchse (B)
Gewindeschart-Getriebe
Schneckenwelle
Schelbe (B)
Buchse (C)
Haltevorrichtung für Schneckenwelle
Schlebestück
Exzentrersperklinke
Buchse (D)
Schelbe (C)
Schlebestückabdeckung
Schraube (F)
Platte
Rückwärtiger Deckel
Schraube (G)
Antriebsrad
Schelbe (D)
Kugellager (D)
Gehäusedeckel
Schraube (H)
Schraube (I)
Buchse (E)
Schraube (J)
Kurbel/Überwurfschraube
Kurbel
Buchse (F)
Schelbe (E)
Buchse (G)