


SPINNING REEL **EMBLEM-Z1500iT/2000iT**



Key No.

Key No.	Parts No.	Parts Name
2-9	F51-1801	Spool assembly
1	F51-8602	Drag knob
2	171-7701	Drag washer retainer
3	E13-6101	Key washer
4	E13-6001	Drag washer
5	E13-6201	Eared washer
6	F51-1901	Spool assembly
7	E13-2101	Click pawl
8	B61-8801	Click spring
9	320-5901	Click retainer
10	E39-4001	Spool washer
11	E36-5301	Click gear
12	F15-8401	Main shaft
13	F33-6102	Rotor nut
14	F50-7803	Rotor assembly
15	F49-6801	Bail trip lever
16	F49-6503	Bail trip cover
17	E36-4202	Bail trip cover screw
18	B67-9308	Line roller screw
19	F49-6203	Bail arm
20	E49-7001	Bail arm screw
21	F44-6303	Line roller collar
22	F44-6202	Line roller washer
23	F05-5601	Ball bearing A
24	F45-4902	Line roller
25	F51-1002	Bail assembly
26	F48-7501	Bail trip cam screw
27	320-5901	Bail trip cam screw retainer
28	320-5901	Bail arm screw retainer
29	E36-8201	Bail spring shaft
30	E51-4401	Bail spring
31	F49-6403	Bail spring cover
32	E36-4202	Bail spring cover screw
33	F19-7202	Oiled washer
34	F15-3301	Roller clutch
35	F21-2501	Roller clutch retainer
36	F26-8501	Spacing sleeve A
37	F15-5101	Spacing sleeve B
38	F15-1201	Anti-reverse ratchet
39	375-8507	Bearing washer
40	F15-1102	Bearing retainer
41	F21-2201	Bearing retainer screw
42	637-5701	Ball bearing B
43	F26-3101	Pinion gear

Key No.

Key No.	Parts No.	Parts Name
44	F15-1002	Pinion gear
45	F51-1601	Body assembly
46	L00-1801	Anti-reverse pawl screw
47	F15-1501	Anti-reverse pawl
48	F15-8301	Anti-reverse pawl collar
49	F15-1601	Anti-reverse pawl spring
50	F15-0701	Anti-reverse cam spring
51	F15-0807	Anti-reverse lever
52	E41-5801	Worm shaft gear
53	F15-1902	Worm shaft
54	F12-2601	Oscillating slider
55	E12-2403	Oscillating pawl
56	E12-4601	Oscillating pawl bush
57	375-0801	Oscillating pawl washer
58	E11-6801	Oscillating slider cover
59	E15-0203	Oscillating slider cover screw
60	375-4101	Worm shaft washer
61	F05-6901	Worm shaft collar
62	F08-7201	Shield plate
63	F15-1701	Pinion collar
64	F15-3707	Water shield
65	F15-3809	Rear cover
66	E24-8101	Rear cover screw
67	E30-6801	Ball bearing C
68	E42-0103	Drive gear
69	375-8501	Drive gear washer
70	637-5701	Ball bearing B
71	F15-2208	Side cover
72	E13-0501	Side cover screw A
73	E13-0501	Side cover screw B
74	F40-4801	Handle collar
75	363-8511	Handle screw
76	F15-4404	Handle cap
77	E15-7502	Side cover screw C
78	F51-1701	Handle assembly

Z2000iT SPECIAL PARTS

Key No.	Parts No.	Parts Name
2-9	F51-2401	Spool assembly
6	F51-2501	Spool assembly
14	F50-9003	Rotor assembly
25	F51-2002	Bail assembly

Parts Name

Parts Name
Pinion gear
Body assembly
Anti-reverse pawl screw
Anti-reverse pawl
Anti-reverse pawl collar
Anti-reverse pawl spring
Anti-reverse cam spring
Anti-reverse lever
Worm shaft gear
Worm shaft
Oscillating slider
Oscillating pawl
Oscillating pawl bush
Oscillating pawl washer
Oscillating slider cover
Oscillating slider cover screw
Worm shaft washer
Worm shaft collar
Shield plate
Pinion collar
Water shield
Rear cover
Rear cover screw
Ball bearing C
Drive gear
Drive gear washer
Ball bearing B
Side cover
Side cover screw A
Side cover screw B
Handle collar
Handle screw
Handle cap
Side cover screw C
Handle assembly

Parts Name

Parts Name
Spool assembly
Spool assembly
Rotor assembly
Bail assembly