




EXPLODED PARTS VIEW

Magnumlite GT-X2100SQ

FIGHTIN' DRAG II



PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION	PART #	DESCRIPTION
RD 0013	(Trip) Lever Spring	RD 0553	Hold Click Spring	RD 1008	Handle Lock Washer
RD 0022	(Bail) Trip Lever	RD 0555	Fightin' Pressure Screw	RD 1023	Handle Screw Cap
RD 0023	Trip Lever Spacer		Washer	RD 1035	Handle Assembly
RD 0026	Ball Bearing	RD 0560	Lever Hold Spring	RD 1036	Rotor
RD 0037	Oscillating Arm	RD 0562	Drag Programmer Screw	RD 1037	Bail Assembly
RD 0039	"C" Lock	RD 0647	Nut Lock Screw	RD 1038	Sic Ceramic Roller
RD 0040	Oscillating Block	RD 0771	Spool Assembly	RD 1039	Side Cover
RD 0041	Drive Gear Washer	RD 0780	Bail Arm	RD 1041	Pinion Gear
RD 0064	Click Gear	RD 0781	Bail Spring	RD 1042	Drive Gear
RD 0071	Rotor Nut	RD 0784	Line Roller Washer	RD 1302	Line Roller Screw
RD 0419	Bushing Washer (B)	RD 0787	Nut Lock Screw	RD 1351	Main Shaft
RD 0533	Anti-Reverse Lock Out	RD 0790	Anti-Reverse Switch (Black)	RD 1354	Drag Click
RD 0534	Pinion Spacer	RD 0792	Bearing Retainer Screw	RD 1355	Drag Washer "C1"
RD 0538	Anti-Reverse Pawl	RD 0793	Anti-Reverse Ratchet	RD 1356	Eared Washer "BF"
RD 0539	Anti-Reverse Pawl Spring	RD 0795	Bushing B	RD 1357	Drag Shaft
RD 0540	Anti-Reverse Pawl Screw	RD 0851	Quick-Fire II Trigger	RD 1359	Lever Click Gear
RD 0543	Side Cover Screw (B)	RD 0930	Ball Bearing	RD 1360	Fightin' Pressure Screw
RD 0544	Drag Washer "C2" (White)	RD 0940	Bail Trip Cam Screw	RD 1395	Body
RD 0548	Key Washer "A"	RD 0943	Bail Spring Cover	RD 1396	Lever Quadrant
RD 0549	Eared Washer "B"	RD 0944	Bail Trip Cover	RD 1397	Fightin' Drag II Lever
RD 0550	Coned Disc Spring	RD 0948	Bail Trip Cover Screw	RD 1398	Drag Programmer
RD 0551	"O" Ring	RD 0949	Trigger Screw		
RD 0552	Pressure Screw	RD 1007	Lock Washer Retainer		